



Wireless Internet Radio

Quick Start Guide



For ongoing product improvement, this manual is subject to modification without prior notice.


MODEL: KWS433

PRODUCT OVERVIEW




Push Button Controls

Power, Play/Pause, Back,
Voice Command/Alarm, Volume+, Volume-



Power Adapter Port
3.5mm Headphone Jack

Micro USB Port
Connect a PC or MAC to transfer
digital files to the built-in 8GB
internal memory



Reset

5W Subwoofer

PACKAGE CONTENTS

Wireless Internet Radio
Quick start Guide
AC adaptor
Warranty card

RADIO AND TV INTERFERENCE STATEMENT


WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee does cause interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

TURN ON/OFF THE DEVICE


Hold on the power button on the top of the device to turn on/off the device.

Home Menu



Open app list Home Back

Settings Menu



NETWORK

Your device support Wi-Fi 802.11b/g/n. Use Wi-Fi settings to manage your device's Wi-Fi connections.

Turning Wi-Fi on or off

Turn your device's Wi-Fi service on or off. When you turn Wi-Fi service on, Your device automatically searches for available, in range Wireless access Points(WAPs).

1. From Home screen, Touch **"SETTINGS"** → **"SETTINGS"**.
2. Touch Wi-Fi to turn Wi-Fi **"ON"** or **"OFF"**.

Scan

Your device scans for available Wi-Fi networks and displays the names of those it finds, Secured networks are indicated with a Lock icon, if your device finds a network that you connected to previously, it connects to it, if not:

1. Touch the Network you want to connect to.
2. Use the keyboard to enter the Password.
3. Touch **"Connect"**.

DISPLAY

Brightness


Set the default screen brightness.

1. From Home screen, touch **"SETTINGS"** → **"SETTINGS"** → **"Display"** → **"Brightness"**.
2. Touch and drag the slider to set the brightness.

Sleep

Set the length of delay between the last key press or screen touch and the automatic screen timeout (dim and lock).


1. From Home screen, touch **"SETTINGS"** → **"SETTINGS"** → **"Display"** → **"Sleep"**.
2. Select the desired setting.



STREAMING MUSIC

If you are using your device for the first time, please follow below instructions how to install the music app onto the device. After the initial setup, you may just touch the music app on the display to stream music.


1. From Home screen, Touch "**STREAMING MUSIC**".
2. Touch "**+**" to see the supported apps.
3. Touch the app that you like to add to your device.
4. Touch "**Yes**" in the pop up window.
5. Touch "**Yes**" to confirm the download (please do not change the screen during download).
6. Touch "**Yes**" to start the installation.
7. Touch "**Next**" and then "**install**" to install the app.
8. Touch "**Open**" to start using the application or "**Done**" to go back to the main menu.



INTERNET RADIO

If you are using your device for the first time, please follow below instructions how to install the radio app onto the device. After the initial setup, you may just touch the radio app on the display to listen to the radio.


1. From Home screen, Touch **"INTERNET RADIO"**.
2. Touch **"+"** to see the supported apps.
3. Touch the app that you like to add to your device.
4. Touch **"Yes"** in the pop up window.
5. Touch **"Yes"** to confirm the download (please do not change the screen during download).
6. Touch **"Yes"** to start the installation.
7. Touch **"Next"** and then **"install"** to install the app.
8. Touch **"Open"** to start using the application or **"Done"** to go back to the main menu.



AUDIO BOOKS

If you are using your device for the first time, please follow below instructions how to install the audio book app onto the device. After the initial setup, you may just touch the audio book app on the display to listen to the audio book.


1. From Home screen, Touch **"AUDIO BOOKS"**.
2. Touch **"+"** to see the supported apps.
3. Touch the app that you like to add to your device
4. Touch **"Yes"** in the pop up window
5. Touch **"Yes"** to confirm the download (please do not change the screen during download)
6. Touch **"Yes"** to start the installation
7. Touch **"Next"** and then **"install"** to install the app
8. Touch **"Open"** to start using the application or **"Done"** to go back to the main menu.



ALARM

If you are using your device for the first time, please follow below instructions on how to set alarms on the device.


1. From Home screen, touch **"SETTINGS"** then touch **"ALARM"**, or press the **"Voice command/Alarm"** button at the top of the device.
2. Touch **"Add alarm"**.
3. Touch **"Time"** to set the desired time and touch **"Done"**.
4. Touch **"Repeat"** to set the days for alarm.
5. Touch **"Label"** to set the name of the alarm.
6. Touch **"Save"**.



WEATHER

If you are using the your device for the first time, please follow below instruction on how to set the weather of the city to be displayed.

1. From Home screen, touch **"SETTINGS"** then touch **"WEATHER"**.
2. Touch **"I Agree"**.
3. Touch **"next"**, and touch **"Do it"**, then type the city name and press Done.



VOICE COMMAND

1. Press and hold the **"Voice command/Alarm"** button at the top of the device.
2. Once prompted on the screen, please say the desired app name you have already installed in the device.
3. you will then see the desired app displaying on the screen.

