
Kids Headphones User's Manual

MODEL: RH301

Instruction





Specifications

• Frequency response: 20Hz - 20kHz

• Impedance: 32Ω ± 15%

• Speaker sensitivity: 85dB ± 3dB

Rated power: 25mwMax input power: 50mw

· Cable length: 1.2m cord with microphone

Plug type: ⊕3.5mm

Notice

- 1. Do not hit or beat the product.
- 2. Do not throw the product into fire.
- 3. Non-professionals do no disassemble the headphones.
- 4. Please use the moderate volume to avoid harming listening.
- Please do no use the headphones in exposed liquid, moisture environment
- 6. For long-time storage, keep the headphones in a well-ventilated place without high temperature sand humidity.
- 7. Cleaning the headphones

Use a cleaning cloth to wipe away dirt on the headphones.
When cleaning the housing with a cloth, do not apply strong force.
Dust the surface first, and then wipe the surface gently using a dry cloth.