

Sungale

Smart TV Box™

Quick Start Guide



For ongoing product improvement, this manual is subject to modification without prior notice.

STB378

Quick Start Guide

Receive up to 45 popular TV channels, watch up to 700 programs in VOD format, stream videos from the most popular video or movie websites, listen over 10K radio stations, Browser, Map, Game, Education, News, Social Media..., all in one, all free, this is Smart TV Box.

1. Accessories:

Here's what you should find inside the packing box:




2. Necessary Surrounding:

- 1) Internet access necessary. For best performance, a connection speed no less than 6 Mbps is recommended. Wi-Fi module is built-in.
- 2) It is strongly recommended to connect the Smart TV Box to your TV set via a HDMI cable. A/V Out Connection is also available, but will not produce a HD output.


3. Setup Steps:

- 1) Connect the Smart TV Box to your TV set with the included HDMI cable.



Quick Start Guide

2) Plug the power adaptor into an outlet, and plug the output end into the Box.



3) Use your TV remote to set your TV's input as HDMI.

4) Press power button on front side for 3 seconds to turn on the box, you will see Start-on Logo, and booting prompt on your TV screen. In approximately 50 seconds later, you will see the home page of the Box.



5) Put two AAA batteries (not included) into the remote controller.

Quick Start Guide

- 6) You will see a focus on the screen. Select the " Wi-Fi" icon on the bottom of the screen, then, following the prompt on the screen, select your wireless network and input your password on the input area. Finally, select "Connect" to link to internet. (See below figures)



- 7) Press "Return" (↵) key on the remote controller to get back the home page, then you can select the programs you want to watch.

4. Main menu overview:




- | | |
|---|---|
| 1 Select the button for Online TV programs | 5 Move the focus up and down for more APPs |
| 2 Select the button to add more Internet video sources | 6 Show if the network is connected |
| 3 Move the focus up and down for more Internet video | 7 Date |
| 4 Select the buttons for all APPs | 8 For more functions |

5. Tips:

- 1) The Smart TV Box will auto-detect the TV's screen size, and auto-fit the display area. In case you find the display area does not fit your television screen, please select "Menu" → "System app" → "Settings" → "Display" → "Screen scale", then press (◀), (▶), (▲), (▼) to adjust the screen display area. (See below figures)



- 2) The default output of the Box is HDMI and AV OUT, so you only need to adjust the input mode of your TV set, don't worry about the output setting of the Box.
- 3) For better remote control result, please make sure the Box front panel face forward, not blocked by any surface. And the best angels to use the remote controller is 90 degrees, see below figure.



6. Remote controller instructions:



Note: Insert remote control receiver into the USB port on the Smart TV Box before you use the remote control.

7. Support:

1. Visit the support site.

- For manual download, FAQs and more supports: www.sungale.com

2. Contact Sungale Support team

- Toll free number in the USA: 800-473-5156
- Service email: service@sungale.com