# ALPHA DIGITAL

# SOLAR POWER BANK User Manual



### Charging the Power Bank

Using the separate USB to Type-C cable, USB micro cable or built-in USB cable to charge this power bank. The digital display screen will flash percentage while charging, and show solid 100% when it's fully charged.

### Using the LED Flashlight

- Turn On: Long press "()" button 3 seconds to switch on the LED lamp.
- Change light modes: Press once "U" button to switch between modes Solid / Blink / Flashing.
- Turn Off: Long press "()" button 3 seconds to switch off the LED lamp.

#### Specifications

Battery Capacity: 20000mAh Battery Type: Li-polymer battery LED Torch: WW camping light Case Material: ABS + PVC Input: DC 5V 2.A Output: DC 5V 2.1A Wireless Output: 5W(5V 1A) Solar Panel: 5V/1.3W Waterproof Level: IP65 Product size: 6.8x3.5x1.1in Product weight: 1.07lb Color: Black, Black+Orange

#### Operation

Using the built-in charging cables, or any other charging cable you have, to connect the power bank to your device. The speed of charging depends on the capacity of your device internal battery. The digital display screen will flsah when it's in use, and indicate how much power is left in the power bank.

#### Security & Maintenance

 Do not heat the unit, or dispose of it in fire, water or other liquids.
Keep away from high humidity,

dusty places.

 Disconnect the unit when fully charged.
Place solar charging panel under direct sunlight and ensure it is facing towards the sun. Do not drop or scratch the solar charging panel.

Dispose of rechargeable batteries carefully. Do not mix battery types.



## ALPHA DIGITAL

<section-header><section-header><section-header><section-header><section-header><text><text><text><text><text><text><text><text><text>