
ALPHA DIGITAL

SOLAR POWER BANK User Manual

MODFI: 71 809

Overview



Charging the Power Bank

Using the separate USB to Type-C cable, USB micro cable or built-in USB cable to charge this power bank. The digital display screen will flash percentage while charging, and show solid 100% when it's fully charged.

Using the LED Flashlight

- 1. Turn On: Double click "(1)" button to switch on the LED lamp.
- 2. Change light modes: Press once "(1)" button to switch between modes Solid / Blink / Flashing.
- 3. Turn Off: Double click "(1)" button to switch off the LED lamp.

Specifications

Battery Capacity: 10000mAh Battery Type: Li-polymer battery LED Torch: 1W camping light Case Material: ABS + PVC Input: DC 5V 2A Output: DC 5V 2.1A Wireless Output: 5W(5V 1A) Solar Panel: 5V/1.3W Waterproof Level: IP65 Product size: 6.3x2.9x0.9in Product weight: 0.63lb Color: Black, Black+Orange

Operation

Using the built-in charging cables. or any other charging cable you have, to connect the power bank to your device. The speed of charging depends on the capacity of your device internal battery. The digital display screen will flsah when it's in use, and indicate how much power is left in the power bank.

Security & Maintenance

- 1. Do not heat the unit, or dispose of it in fire, water or other liquids.
- Keep away from high humidity, dusty places.
- 3. Disconnect the unit when fully charged. 4. Place solar charging panel under direct sunlight and ensure it is facing towards the sun. Do not drop or scratch the solar charging panel.

Dispose of rechargeable batteries carefully. Do not mix battery types.









ALPHA DIGITAL

WARRANTY

The limited warranty set forth below is given by the manufacturer with respect to ALPHA DIGITAL brand DPF players and other consumer electronics products purchased and used in the United States of America. The manufacturer warrants this product against defects in material or workmanship as follows:

LABOR: For a period of innety (90) days from the date of purchase if this Product is defective, the manufacturer will replacement parts.

PARTS: For a period of ninety (90) days from the date of purchase if this Product is defective, the manufacturer will replacement parts in exchange for defective parts, After this innet; (90) days period up to one year, a labor charge of US\$30.00 will be charged for each service.

PARTS: For a period of one year fromthe date of purchase, the manufacturer will supply, at no charge, new or rebuilt replacement parts in exchange for defective parts, After this one year period, the manufacturer will charge the new or replacement parts in exchange for defective parts, After this one year period, the manufacturer will charge the new or replacement parts of the product, (3) damage due to improper operation, improper maintenance, or connection to an improper voltage supply; (6) damage due to an attempted repair of the Product by anyone other than a facility authorized by the manufacturer to service the Product; (7) consumables (such as fuses and batteries). This warranty is valid only in the Unlets States.

The product must be accompanied by a copy of the original retail purchase receipt. If no proof of purchase is attached, the warranty will not be honored and repair cost will be charged.

This warranty is valid with attach written documentation detailing the complaint to the outside or inside of the carton.

The manufacturer reserves the right to modify any design of this product without prior notice.

To obtain warranty service, you must deliver the product freight prepaid, in either its original packaging or packaging affording an equal degree of protection, plus product with