


INSTRUCTIONS FOR USE



Installation steps




1: Align the tab on one side with the VR plugin



2: Align and insert the other side as before




3: Adjust the node of VR to a comfortable position



4: Start VR after installing the adjustment

Headstrap

Instructions



1 Charging process	Digital Display Power
2 Screen Rest Time	Turn Off After 30 Seconds
3 LED Function	Colorful Effect
4 Protection Function	Short Circuit Protection

Capacity: 6000mAh 20.14Wh
Add time: 3H
Output: 5V/2A
Input: 5V/2A
Weight: 476g
Color: White & Black